


GoldStar SERVICE MANUAL

BEFORE SERVICING THE CHASSIS, READ THE "SAFETY




MODEL: CN-14A80


GCT1304M(CN-14A82)


GCT1354M(CN-14A84)


GCT1904M(CN-20A82)

















WARNING : BEFORE SERVICING THIS CHASSIS, READ THE 'X-RAY RADIATION PRECAUTION.' 'SAFETY PRECAUTION' AND PRODUCT SAFETY NOTICE' IN THIS MANUAL

CAUTION: The Δ marks in the schematic diagram and the parts list designate components which have special characteristics for safety, and should be replaced only which types identical to those in the original circuit or specified in the parts list. Before replacing any of these components, read carefully the PHODUCT SAFETY NOTICE in this manual. Do not degrade the safety of the receiver through improper servicing.

AVIS SUR LA SECURITE DU PRODUCT

Les pièces de la partie ombrée possdent d'importantes caratéristiques speciales par rapport à la sécurité et avant de les remplacer. il est recommandé de lire le manuel de service. No maitraitez pas le recepteur car vous pourriez en endommager le système securitaire.

. . .

1. Resistance is shown in ohm. K=1.000 M=1.000.000

Capacitors are shown in uF otherwise noted: P = uu

Unless otherwise listed. all inductor values more than 1 are expressed in uH. and the values less than 1 in H.

. Voltages are measured DVM from point indicated to chassis ground. Using color bar signal with all controls at normal.

5. Waveforms are measured with synchroscope from point indicated to chassis ground using color bar with all controls at normal.

May choose anyone, since listed following semiconductors have same characteristics EQUIVALENT CIRCUIT BLOCK DIAGRAM

